

Quick Start Guide

SHAQ™ ShaqPot Pressure Cooker

See owner's manual for complete instructions and important safety information before using this product.

STEP 1



Slide the Release Switch to the Open position. Release the Switch and twist the Lid clockwise. When the Lid Position Mark is aligned with the Open Mark, lift the Lid to remove.

STEP 2



Place the Inner Pot inside the appliance Base.

STEP 3



Add your ingredients. Do not fill past the FULL line in the Inner Pot.

STEP 4



Place the Lid on top of the Base, aligning the Lid Position Mark with the Open Mark. Twist the Lid counterclockwise about 30°. When the Lid is locked, the Release Switch will automatically move to the Closed position.

STEP 5



Select a cooking preset button on the sides of the Digital Display. Use the Center Dial to select a food type. Press the Center Dial to confirm the cooking time and temperature settings and start the cooking process.

Unpack all parts from the box and remove any clear or blue protective film on the components. Wash the inner and outer lid, gasket, accessories, and the outside of the base with warm, soapy water before first use (only select accessories are dishwasher safe).