COOK'S COMPANION

TEA KETTLE

USING YOUR TEA KETTLE

- Before first use, wash the tea kettle with warm soapy water.
- Fill your kettle through the large lid opening on the top, never fill the kettle with water above the pour spout. Then place the lid on top of the kettle. NOTE: Overfilling the kettle can cause hot water to spurt through the openings.
- For your kettle to best perform the diameter of the burner should not be larger than the base of the kettle. If on a gas burner, the flame should only touch the bottom not the sides.
- The kettle will begin to whistle once it has reached a boil, turn off the burner and wait thirty seconds before pouring. Press the pour tab in the handle to start pouring. Use potholders or oven mitts when handling a hot kettle.

CARING FOR YOUR TEA KETTLE

- Hand washing is recommended and will prolong the tea kettles beauty.
- Allow your tea kettle to cool before submerging into water.
- Do not use abrasive or harsh cleaners.
- Always use extreme caution when handling a hot tea kettle and keep out of reach of children at all times.
- Do not use the tea kettle in a microwave or oven.
- Always use oven mitts or potholders when handling a hot tea kettle.
- Always place on a heat resistant surface after boiling.
- NEVER LET YOUR KETTLE BOIL DRY OR ALLOW A DRY KETTLE TO REMAIN ON A HOT BURNER.

NOTES

LIMITED ONE YEAR WARRANTY

This warranty covers all defects in workmanship or materials in the parts, arising under normal use and care in this product for a period of one year from the date of purchase provided you are able to present a valid proof-of-purchase. A valid proof-of-purchase is a receipt specifying item, date purchased, and cost of item. A gift receipt showing item and date of purchase is an acceptable proof-of-purchase. Product is intended for household use only. Any commercial use voids the warranty.

This warranty covers the original retail purchaser or gift recipient. During the applicable warranty period within normal household use, we will repair or replace, at our discretion, any part which proves defective, or replace unit with a comparable model. Shipping and handling costs are not included for warranty replacements and are the responsibility of the customer.

To obtain service under the terms of this warranty, send an email to customercare@alliedrich.net or call 312-526-3760. Please provide the model number listed on the bottom of this page when contacting us.

THIS LIMITED WARRANTY COVERS UNITS PURCHASED AND USED WITHIN THE UNITED STATES AND DOES NOT COVER:

- Ordinary wear and tear including scratches, dents or stains.
- Heat discoloration, minor imperfections and slight color variations in the ceramic coating, metals or glass.
- Damage caused by extreme temperatures changes such as pre-heating cookware empty, letting liquids boil dry or immersing a hot pot or lid into cold water.
- Improper cleaning methods causing scratches.
- Damages in transit.
- Defects other than manufacturing defects.
- Damages from misuse, abuse, accident, alteration, lack of proper care and maintenance.
- Damage from service by other than authorized dealer or service center.
- Shipping and handling costs.
- This warranty gives you special legal rights and you may also have other rights to which you are entitled which may vary from state to state.

Manufacturer does not assume responsibility for loss or damage for return shipment. We recommend that you keep your original packaging should you require repair service. Before returning product please contact our customer care department for return authorization. When returning product for repair please include your full name, return address, and daytime phone number. Also include a brief description of the problem you are experiencing and a copy of your sales receipt or other proof of purchase in order to validate warranty status.

MODEL CCTK1

COOK'S COMPANION