


ACTIVA

2.4G RC DINOSAUR

QUICK GUIDE



HIGH PERFORMANCE TYRANNOSAURUS REX FUNCTIONS:



IMPORTANT NOTE:

Prior to using your RC Dinosaur for the first time, ensure it is fully charged.

REMOTE CONTROL OVERVIEW:



Remote Control Uses
2x 1.5V AA Batteries
(Batteries not included)

HOW TO CHARGE:

- Locate the battery compartment on the tail of the dinosaur and remove the 4.8V battery.
- Connect a USB cable to the battery, and then to a power source to begin charging the dinosaur.
- Allow to charge for 2-3 hours to charge completely.
- On a full charge, the dinosaur can operate for 15- 20 minutes.
- Please note, while charging, the charging indicator light will be red and flashing. Once fully charged, this indicator light will be off.

For safety concerns, battery charging must be done under adult supervision at all times.

PRODUCT SPECIFICATIONS:

- Size of product itself: 42*13.5*23cm
- Net weight of product itself: 0.6KG
- Single package size: 42x14x24.5cm
- Net weight of product including package: 0.9KG
- Materials: ABS

LIMITED LIFETIME WARRANTY

Your product is backed by a limited lifetime manufacturer's warranty. Activa will repair or replace your device at any time should it fail due to a defect in material or workmanship, subject to the certain limitations.

This limited warranty does not cover any damage that results from unauthorized or improper use, service, or repair. Further, it does not cover damage caused by accident, impact, negligence, or normal wear and tear. Should you discover your product is not functioning properly, please send your device to our repair center for evaluation. If your product cannot be repaired or serviced, we will reserve the right to change it for a similar or newer model.

Please note that a flat rate of \$15.00 will be charged to cover a service evaluation fee and return shipping of your device. All warranty claims must be accompanied by a copy of your proof of purchase from an authorized retailer. Please send your device, proof of purchase, and a check or money order in the amount of \$15.00 made out to Activa to:

Address:

Activa Service Center
3069 Taft Street
Hollywood, FL 33021

Contact:

warranty@activaofficial.com

ACTIVA