

90 DAY LIMITED WARRANTY

Course Housewares, LLC warrants this Cook's Companion® product to be free from manufacturer defect for up to 90 Days from the original date of purchase. If a defect is found to exist, Course Housewares will, at its option, either repair or replace the product or the defective component, including labor. Replacement will be made with a new or rebuilt product or components. This warranty does NOT cover (a) ordinary wear and tear (such as scratches, chips or stains, (b) impact damage or breakage, (c) heat discoloration, minor imperfections and slight color variations in the silicone or metals, which are a normal part of the craftsmanship, (d) extreme temperature or resulting damage to the product (e) improper cleaning methods causing scratches or damage, or (f) any unit that has been tampered with, (g) damages incurred through improper use and care and (h) faulty packaging by you or mishandling by any common carrier. Failure to follow the accompanying Care and Use instructions or commercial use will void this warranty.

Course Housewares' sole obligation and your exclusive remedy under this warranty is limited to repair or replacement, at its option, of the defective product. You will be responsible for any shipping and handling fees. Products returned to us that are not found to be defective in material or workmanship will be returned to you. If your particular product is found defective but is no longer available and cannot be repaired, a comparable product, at our discretion, will be sent as a replacement. This warranty extends only to the product's original purchaser, US residents only and does not cover damage caused by improper use or accidental damage. This warranty covers the Square Basket and Tong only.

COURSE HOUSEWARES, LLC MAKES NO OTHER WARRANTIES, EITHER EXPRESSED OR IMPLIED, REGARDING THE PRODUCT OR RELATING TO ITS QUALITY. PERFORMANCE, MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE, COURSE HOUSEWARES, LLC SHALL NOT BE LIABLE FOR INDIRECT, CONSEQUENTIAL OR SPECIAL DAMAGES WHETHER A CLAIM IS BASED ON CONTRACT, TORT, WARRANTY OR OTHERWISE, IN NO EVENT WILL LIABILITY EXCEED THE ORIGINAL PURCHASE PRICE OF THE PRODUCT. THE DURATION OF ANY IMPLIED WARRANTY WHATSOEVER, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THE EXPRESS WARRANTY PROVIDED HEREIN. COURSE HOUSEWARES SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES WHATSOEVER.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may have other legal rights, which vary from State to State.

To Process a claim:

Do not return the product to the retailer from which it was purchased. Your retailer has no liability for this warranty. Please contact the Course Housewares customer service department for assistance and to ensure the fastest possible resolution to the problem. Please have your purchase information available to speed this process.

OR


Send your name, physical address, phone number, original purchase receipt and the safely packaged item prepaid to:

Course Housewares, LLC
1715 Lake Drive West
Chanhassen, MN 55317
(866) 325-1659

Return shipping and handling charges may apply.

MADE IN CHINA


MODEL: CCPWUPS17/B411295



COOK'S[®] COMPANION

Square Cookware Basket & Tong Set





COOK'S COMPANION®

PLEASE READ BEFORE USE AND SAVE THESE INSTRUCTIONS

Thank you for purchasing Cook's Companion® Square Basket & Tong Set. Your accessories will perform best when used as intended. To ensure the best performance of your product, please consistently follow these instructions.

About Cook's Companion®

Whether you are a culinary novice or frittata flipping, soufflé-rising, flambéing master chef, every great cook needs a fine set of tools at his or her disposal to create a truly stellar dish. Exclusively available through Evine, the Cook's Companion® line sets the professional standard for quality tools offered at economic prices. Whether you're prepping meals for one, two or 20, this essential collection can cater to your any and every gastronomic need.

Select from among Cook's Companion® cookware, bakeware, and cutlery guaranteed to make prep easy as pie. These high-quality kitchen essentials combine innovative and resourceful industry technologies with colorfully stylish designs. In addition, Cook's Companion® products boast features and functions employed for easy care and cleanup. Cook's Companion® deliberately constructs each product with ease and convenience in mind. Fill your kitchen with useful products and return the joy to cooking with assistance from this dependable brand. Be a dinner winner with go-to cookware, bakeware, cutlery and other exclusive essentials from Cook's Companion®.

GETTING STARTED

- ◆ Before using, remove any labels and wash and dry each item in accordance with the care and use instructions.
- ◆ For best results, read through these instructions before first use.

COMPATIBILITY

- ◆ The Cook's Companion® Square Basket is compatible with the Cook's Companion® 8QT. Perfect Weight Squared Stock Pot (not included).
- ◆ The Square Basket is not intended for any stovetop, microwave, or oven use.
- ◆ Your Tong is a universal tool and can be used with any suitable cookware or serveware.

CARE & USE

- ◆ Although the Cook's Companion® Square Basket and Tong are dishwasher safe, hand washing with warm soapy water and a soft sponge or towel is recommended and will prolong the cookware's beauty.
- ◆ Allow your accessories to cool before submerging into water.
- ◆ Do not use abrasive or harsh cleaners.
- ◆ Do not scratch the surface or cut directly on your cookware.
- ◆ Always use extreme caution when handling and keep out of reach of children at all times.
- ◆ Always use oven mitts or potholders when handling any part of your accessory set.
- ◆ Do not use in a microwave.

Using Your Square Basket

- ◆ The Square Basket allows you to easily steam, boil, fry, and strain many different types of food in your 8QT. Perfect Weight Square Stock Pot (not included).
- ◆ It is recommended to first place your food into the basket while the water is heating up in the square stockpot (not included). Once the water has been brought to a boil or the desired temperature, gently lace the basket into the pot (not included) using the basket's silicone handles.
- ◆ Be very careful when placing the square basket into the pot (not included), to avoid any spilling.
- ◆ We recommend only filling the stockpot (not included) up half way before placing the basket into the pot, as the liquid will rise depending on the weight and volume of the basket. Over filling the pot with liquid can cause the water to overflow once the basket is placed into the 8QT. Square Stock Pot (not included).
- ◆ It is recommended to always use the silicone portion of the handles on the basket when handling.
- ◆ CAUTION: The silicone will still become hot, it is important to always use oven mitts or a towel when handling the square basket.



Using Your Tong

- ◆ When using the tongs use care to contact the food directly and avoid scraping your cookware.
- ◆ Never leave the Tong resting inside a pot or pan when using.
- ◆ While the tong is dishwasher safe, we recommend hand washing with warm soapy water and a soft sponge or dishtowel to prolong the life and beauty of this product.
- ◆ To open the tong, simply push the black knob on the handle inwards.



- ◆ To close the tong, gently pull the black knob outwards while holding the tong closed so that both tongs are together.

