

## 1 YEAR LIMITED WARRANTY

Course Housewares, LLC warrants this Cook's Companion® product to be free from manufacturer defect for up to 1 year from the original date of purchase. If a defect is found to exist, Course Housewares will, at its option, either repair or replace the product or the defective component, including labor. Replacement will be made with a new or rebuilt product or components. This warranty does NOT cover (a) ordinary wear and tear (such as scratches, dents, chips or stains), (b) impact damage or breakage, (c) heat discoloration, minor imperfections and slight color variations in the metals, silicone, or any other part thereof, which are a normal part of the craftsmanship, (d) extreme temperature (such as pre-heating Bakeware empty, letting liquids boil dry, immersing hot pan in cold water) or resulting damage to the product and/or other property, (e) improper cleaning methods causing scratches or damage to the unit itself, or (f) accessories, even if sold with the product, (g) any unit that has been tampered with, (h) damages incurred through improper use and care and (i) faulty packaging by you or mishandling by any common carrier. Failure to follow the accompanying Care and Use instructions or commercial use will void this warranty.

Course Housewares' sole obligation and your exclusive remedy under this warranty is limited to repair or replacement, at its option, of the defective product. You will be responsible for any shipping and handling fees. Products returned to us that are not found to be defective in material or workmanship will be returned to you. If your particular product is found defective but is no longer available and cannot be repaired, a comparable product, at our discretion, will be sent as a replacement. Course Housewares cannot guarantee a replacement of the same color as your original purchase. This warranty extends only to the product's original purchaser, US residents only and does not cover damage caused by improper use or accidental damage. This warranty covers the Dilitanium™ Crisper Pan only.

COURSE HOUSEWARES, LLC MAKES NO OTHER WARRANTIES, EITHER EXPRESSED OR IMPLIED, REGARDING THE PRODUCT OR RELATING TO ITS QUALITY. PERFORMANCE, MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE, COURSE HOUSEWARES, LLC SHALL NOT BE LIABLE FOR INDIRECT, CONSEQUENTIAL OR SPECIAL DAMAGES WHETHER A CLAIM IS BASED ON CONTRACT, TORT, WARRANTY OR OTHERWISE, IN NO EVENT WILL LIABILITY EXCEED THE ORIGINAL PURCHASE PRICE OF THE PRODUCT. THE DURATION OF ANY IMPLIED WARRANTY WHATSOEVER, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THE EXPRESS WARRANTY PROVIDED HEREIN. COURSE HOUSEWARES SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES WHATSOEVER.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may have other legal rights, which vary from State to State.

To Process a claim:

Do not return the product to the retailer from which it was purchased. Your retailer has no liability for this warranty. Please contact the Course Housewares customer service department for assistance and to ensure the fastest possible resolution to the problem. Please have your purchase information available to speed this process.

OR


Send your name, physical address, phone number, original purchase receipt and the safely packaged item prepaid to:

Course Housewares, LLC  
1715 Lake Drive West  
Chanhassen, MN 55317  
(866) 325-1659

Return shipping and handling charges may apply.


MADE IN CHINA

MODEL: CCCPDT1/B413484



# COOK'S<sup>®</sup> COMPANION

## Dilitanium™ Crisper Pan





*Thank you for purchasing Cook's Companion® Ditanium™ Crisper Pan. Cook's Companion® will perform best when used as intended. To ensure the best performance of your product, please consistently follow these instructions.*

## PLEASE READ BEFORE USE AND SAVE THESE INSTRUCTIONS

---

### About Cook's Companion®

Whether you are a culinary novice or frittata flipping, soufflé-rising, flambéing master chef, every great cook needs a fine set of tools at his or her disposal to create a truly stellar dish. Exclusively available through Evine, the Cook's Companion® line sets the professional standard for quality tools offered at economic prices. Whether you're prepping meals for one, two or 20, this essential collection can cater to your any and every gastronomic need.

Cook's Companion® combines innovative and resourceful industry technologies with colorfully stylish designs. In addition, Cook's Companion® products boast features and functions employed for easy care and cleanup. Cleverly designed with non-stick interiors and ceramic coating, Cook's Companion® deliberately constructs each product with ease and convenience in mind. Fill your kitchen with useful products and return the joy to your kitchen with assistance from this dependable brand. Please enjoy this exclusive essential from Cook's Companion®.

### Getting Started

- ◆ Before using, remove any labels and wash and dry each item in accordance with the care and use instructions.
- ◆ For best results, season your PFOA/PTFE Free nonstick coating by lightly rubbing cooking oil onto the nonstick surface. Warm the Crisper Pan in your conventional oven at 225 degrees for 2-3 minutes, let cool and wash again. You are now ready to enjoy your Cook's Companion® Ditanium™ Bakeware.

### Cleaning Your Ditanium™ Bakeware

- ◆ Cook's Companion® Ditanium™ Bakeware uses PFOA/PTFE Free nonstick coating, making it easy to clean. While Cook's Companion® Bakeware is dishwasher safe, hand washing is recommended and will prolong the bakeware's beauty.
- ◆ Always allow your Bakeware to cool before submerging into water.
- ◆ Do not use abrasive or harsh cleaners.

### Using Your Ditanium™ Bakeware

- ◆ Never use metal utensils on any nonstick surface. It is recommended that you use tools made of nylon, plastic, wood or melamine.
- ◆ Do not scratch the surface or cut directly on your Bakeware.
- ◆ Always use extreme caution when handling hot Bakeware and keep out of reach of children at all times.
- ◆ Cook's Companion® Ditanium™ Bakeware is oven safe to 450°F.
- ◆ Always use oven mitts or potholders when handling.
- ◆ Do not use in a microwave.
- ◆ Never use any aerosol cooking sprays on your Bakeware. This will damage the nonstick coating and will void your warranty.

### Your Crisper Pan

- ◆ Your Cook's Companion® Crisper Pan can be used on its own, as a perforated pan, or you can place the Crisper Pan onto any Cook's Companion 9x13 Bakeware Pan (not included) when wanting grease to drain through.
- ◆ When placing the Crisper Pan onto another pan, do so gently so that you do not scratch your bottom pan.
- ◆ The crisper pan can be used for anything from Garlic Bread to baking Bacon and is a great tool for in the kitchen.