

ACTIVA


PORTABLE BLADELESS & COOLING NECK FAN



USER MANUAL

PRODUCT OVERVIEW


Power Indicator Light



Type-C Charging Port

Power Button/Fan Speed

TPU Hose



Air Outlet

Air Inlet

PRODUCT SPECIFICATIONS

- Battery Capacity: 4000mAh (14.8Wh/3.7V)
- Input: DC5.0V = 1.0AMAX
- Battery Type: Lithium-ion battery
- Fan power: 5W MAX
- Blade material hardness: vD60 Shore
- Fan speed: 2m/s MAX
- Charging time: 4 hours
- Working time: 4-9 hours (depending on different gears/usage scenarios)
- Executive standard: Q/JS008-2017
- Product Size: 218(L)mm x 169(W)mm x60(H)mm
- Product Material: ABS + Silica gel + Stainless Steel
- Size of package: 245*165*70mm
- GW with package: 450g

PACKAGING INCLUDES

- 1x Portable Bladeless & Cooling Neck Fan
- 1x Type-C Charging Cable
- 1x Manual
- 1x Carrying Pouch
- 2x 2000mAh Rechargeable Lithium-ion Batteries (Built-in)

SAFETY PRECAUTIONS

1. When using, do not place your hair too close to the air inlet, so as not to get your hair caught in the air cavity.
2. When the fan is in operating use and the white light flashes quickly, this indicates that the remaining power is too low and that the device needs to be charged.
3. Please do not open or bend the TPU hose with excessive force to avoid damaging the product.
4. The battery must not be disassembled, hit, squeezed, or thrown into a fire. If severe swelling occurs, immediately discontinue use of the device. Do not place the product in a high temperature environment.


WARNING

1. This product uses lithium-ion batteries. Overcharging or over discharging the battery will affect the usage life of the product. Charge periodically and disconnect the power once fully charged.
2. Do not insert your fingers into the air inlet or outlet cavities while the device is turned on and in use.
3. This product is NOT a children's toy. Children under the age of 14 must always be supervised while using the product.
4. Do not squeeze, disassemble the battery or leave the battery in a high temperature environment (140°F and above), for doing so will damage the device. There is a risk of leakage or explosion.
5. Do NOT use this product while it is charging.

HOW TO USE


Instructions

- From left to right, gently hang the device around your neck with the air outlet facing upwards.
- Press the power button to activate the fans. Air will begin to blow out from the air outlets, providing a cooling effect.



Turning Device On & Adjusting Fan Speed

- To turn on the device, simply press the power button.
- To switch between the 3 different fan speed levels (first gear: 3800 rpm, second gear: 4000 rpm, third gear: 4500 rpm), short press the power button once each time.



Cleaning And Maintenance

- Before cleaning this product, make sure that the power has been shut off.
- Wipe the device's body and air outlets off with a dry cloth.
- Make sure to religiously remove dust or any other obstructive items from the air outlets to prevent them from blocking or falling into the air outlets, causing damage.
- Do NOT clean electrical parts (such as the motors, power switches, etc.) with water or other liquids.

CHARGING INSTRUCTIONS

This product has two built-in and rechargeable 2000mAh lithium-ion batteries with a long battery life. Usage time of the device on a fully charged battery is 4-9 working hours, depending on fan speed settings and the environment in which the product is being used.

Power Indicator Status:

Dicator Light Color	Status
White Light	Working
Slow Flashing White Light	Charging
Quick Flashing White Light	Battery is Less than 15% (Need to Charge)
Light is Off	Power is Off or Device is Fully Charged

LIMITED LIFETIME WARRANTY

Your product is backed by a limited lifetime manufacturer's warranty. Activa will repair or replace your device at any time should it fail due to a defect in material or workmanship, subject to the certain limitations.

This limited warranty does not cover any damage that results from unauthorized or improper use, service, or repair. Further, it does not cover damage caused by accident, impact, negligence, or normal wear and tear. Should you discover your product is not functioning properly, please send your device to our repair center for evaluation. If your product cannot be repaired or serviced, we will reserve the right to change it for a similar or newer model.

Please note that a flat rate of \$9.00 will be charged to cover a service evaluation fee and return shipping of your device. All warranty claims must be accompanied by a copy of your proof of purchase from an authorized retailer. Please send your device, proof of purchase, and a check or money order in the amount of \$9.00 made out to Activa to:

Address:

Activa Service Center
3069 Taft Street
Hollywood, FL 33021

Contact:

warranty@activaofficial.com