

ACTIVA

TWIST CAR

USER MANUAL

PRODUCT INFORMATION AND TIPS:

The Twist Car is suitable for children ages 10 and up. The car is an electronic product so should be used under adult supervision. To avoid injury or damage, do not modify or disassemble.


1. The remote control requires 2 1.5V AA non-rechargeable batteries.
2. The car requires one 6V 2/3AAA Ni-MH battery pack, which is a rechargeable battery pack..
3. Please note the polarity symbols to insert batteries correctly.
4. Do not attempt to recharge the non-rechargeable batteries.
5. Avoid short-circuiting the car.
6. Adult supervision is required when charging the rechargeable battery.
7. Check the cord, plug, power switch, enclosure and other parts regularly to ensure continued optimum performance. Discontinue use if any parts are damaged.
8. When not in use, make sure that the power switch is "OFF" and remove the batteries in the car body and remote control.
9. Do not immerse in water.
10. The packaging contains important information, keep it stored for future reference.

PRODUCT OVERVIEW:

Product configuration



Part designations



REMOTE CONTROL INFORMATION AND INSTRUCTIONS:

1. Place the batteries in the remote control. The indicator light of remote control will start flashing. Then, load batteries in the car and switch it on. The car and remote signals will connect. Once connected, the flashing indicator light will switch off.
Note: If the signal connection fails, repeat the steps above.
2. You can only use 1 remote control per car.
3. When the remote control fails to locate the car's 2.4G signal for one minute, it will automatically enter Sleep Mode. Press any button to exit the Sleep Mode.

BATTERY INSTALLATION:

Remote Control-

1. Remove the remote control battery cover and load batteries according to polarity symbols.
2. Replace the battery cover.


Twist Car-

1. Remove the battery cover underneath the car connect the rechargeable battery pack to the power socket and place in the battery box.
2. Replace the battery cover and secure with a screwdriver.




CHARGING THE BATTERY PACK:

1. Charge battery pack prior to first use.
2. Connect the battery pack to the port of the USB charging cable. Then plug in the USB charging cable to a socket.
3. Charging time is 3-4 hours. The USB cable indicator light will turn red when charging and turn off when fully charged. Do not over charge, it will not change battery capacity limit.
4. Check the car battery, charging cable, plugs and other parts regularly for optimum performance.



CAR CONTROL:

1. Turn on the car.
2. Push the direction lever of the remote control to let the car run forward/backward or turn left/right.
3. Turn the power off when not in use.
4. Press the transformation button to transform the car. Note: Only one side transforms.
5. When finished using, turn off the car's power and the remote will automatically enter sleep mode.



OPERATING TIPS:

1. Always ensure the power switch is 'ON' when the vehicle is being operated.
2. A low battery will impact the car's movement capability.
3. The Twist Car's control range is approximately 40 meters (131 feet). The car will stop running once out of control range.

TROUBLE SHOOTING:

Problems	Causes	Solutions
The car has no response.	The remote control failed to connect, or the car is switched to "OFF".	Turn the car on and repeat the signal connection steps.
	The remote control and remote control car batteries are installed improperly.	Install the batteries according to the polarity instructions in the battery box.
	The power of the rechargeable battery pack is low.	Fully charge the battery pack.

Problems	Causes	Solutions
The car is out of control, or the control range becomes short.	The batteries of the remote control are low, or the power of the battery pack is low.	Replace with new batteries for the remote control, or charge the car's battery pack.
	There may be signal interference near the site of use	Replace the battery.

MAINTENANCE AND SAFETY:

1. To avoid short circuiting or fire, do not use near an open flame and keep away from direct sunlight, high temperatures or humidity.
2. When transporting or storing, place the car back in original packaging and keep in a cool dry place.
3. Use a soft, dry cloth to clean the car.
4. To avoid injury, do not touch the wheels while the car is moving.
5. Do not use on an active road or 'drive' through water.
6. Be careful to not cause damage to the furniture or glass when playing the car in the room.
7. Play in safe outdoor environments, do not use the car on an active road or in a crowd.
8. Do not use during a thunder and/or lightning storm.
9. Avoid contact with hair and clothes while operating
10. Do not drive the car toward to people.

LIMITED LIFETIME WARRANTY

Your Activa Twist Car is backed by a limited lifetime manufacturer's warranty. Activa will repair or replace your device at any time should it fail due to a defect in material or workmanship, subject to the certain limitations.

This limited warranty does not cover any damage that results from unauthorized or improper use, service, or repair. Further, it does not cover damage caused by accident, impact, negligence, or normal wear and tear. Should you discover your Activa Twist Car is not functioning properly, please send your device to our repair center for evaluation. If your product cannot be repaired or serviced, we will reserve the right to change it for a similar or newer model.

Please note that a flat rate of \$30.00 will be charged to cover a service evaluation fee and return shipping of your device. All warranty claims must be accompanied by a copy of your proof of purchase from an authorized retailer. Please send your device, proof of purchase, and a check or money order in the amount of \$30.00 made out to Activa to:

Address:

Activa Service Center
3069 Taft Street
Hollywood, FL 33021

Contact:

warranty@activaofficial.com