

installation instruction



① Remove the base



support



② Align the base bayonet and press down the bracket



Disinfection
light tube



Lamp cap



③ Align the socket of the lamp holder and insert the sterilization light tube

④ Align the lamp cap bayonet and press down the lamp cap

Ultraviolet sterilization lamp operating instructions

1.Product Parameter

Model Number	UVH3	Type of Lamp-house	Quartz ultraviolet light source
Material	PC	Applicable area(m ²)	50-60
Product Net Weight (kg)	1.1	Power(W)	60W
Product Dimension(mm)	210*460	Rechargeable	Not available
Operating Voltage(V)	110V	Ozone or not	Not available
Installation Method	Pedestal	Control Mode	Remote control/Timing

2.Function

2-1 Adopt quartz glass ultraviolet lamp with high penetration rate and better sterilization effect.

2-2 oval three-dimensional design

2-3 UV sterilization

2-4 Remove methanol and remove odor

3.Use and precautions

3-1 Starting method:remote control.Power on-Press the remote control key-The lamp tube begins to work-Choose the timer gear(15/30/60 minutes)-"beep"one time to enter timer mode.

3-2 Ultraviolet characteristics:Wavelengths irradiate microbes to destroy their DNA and RNA,so that the bacteria lost the sterility ability to survive and reproduce so as to achieve disinfection and sterilization.

3-3 After the lamp is turned on,keep away from the room.Leave the disinfection space for people/animals.Ventilate for 30minutes after disinfection

3-4 Prolonged exposure to ultraviolet light can cause damage to the eyes and skin of humans/animals. Therefore,people and animals should leave the room when the disinfection is carried out in a confined space.

3-5 Generally disinfect 2-3times one week.

3-6 The service life of the lamp tube is 6000 hours,the warranty of the lamp tube warranty one year(Exclude man-made damage).

3-7 Within a reasonable sterilizing time,ultraviolet rays do little harm to clothing,furniture,etc.

3-8 Usage time reference:bedroom(15/30 minutes)kitchen toilet(15/30 minutes)living room(60 minutes).

Note:during use,please follow the instructions.If you are accidentally irradiated by ultraviolet light for a long time and find your eyes sore or skin red and itchy,please seek medical advice immediately.