

Ultraviolet sterilization lamp operating instructions

1. Product Parameter

Model Number	UVH7	Type of Lamp-house	Quartz ultraviolet light source
Material	ABS	Applicable area	430 sq ft.
Product Net Weight (kg)	1.1	Power (W)	36W
Product Dimension (mm)	410*105*180MM	Rechargeable	Not available
Operating Voltage (V)	110	Ozone	Not available
Installation Method	Pedestal	Control Mode	Remote control/Timing

2. Function

- 2-1 Adopting quartz glass ultraviolet lamp tube, the penetration rate is high, the sterilization effect is better.
- 2-2 Remove the odor of methanol.
- 2-3 Ultraviolet sterilization.

3. Use and Precautions

3-1 Starting mode 1: Remote control. Plug in the power - Switch on - The indicator light flashes - Press the remote control key (red power button) - Choose the timer mode (15/30/60 minutes) - Press the remote control then there will be a "beep" (red power button) - Wait for 5 seconds - Enter into the start mode (Continuous "beep" for 30 seconds) - The lamp is started

3-2 Starting mode 2: Button control. Plug in the power - Switch on - The indicator light flashes - Press the timer button (black button) - Choose the timer mode (15/30/60 minutes) - A "beep" - Wait for 5 seconds - Enter into the start mode (Continuous "beep" for 30 seconds) - The lamp is started

3-3 Ultraviolet characteristics: Wavelengths irradiate microbes to destroy their DNA and RNA, so that the bacteria lost the ability to survive and reproduce so as to achieve disinfection and sterilization.

3-4 After the lamp is turned on, people or animals should leave the disinfection space. Ventilate after disinfection with the UV lamp.

3-5 Prolonged exposure to ultraviolet light can cause damage to the eyes and skin of humans/animals. Therefore, people and animals should leave the room when the disinfection is carried out in a confined space.

3-6 Generally disinfect 2-3 times one week.

3-7 The service life of the lamp tube is 6000 hours.

3-8 Within a reasonable sterilizing time, ultraviolet rays do little harm to clothing, furniture, etc.

3-9 Usage time reference: bedroom (15/30 minutes) kitchen toilet (15/30 minutes) living room (60 minutes).

Note: during use, please follow the instructions. If you are accidentally irradiated by ultraviolet light for a long time and find your eyes sore or skin red and itchy, please seek medical advice immediately.