




Breadmaker Ice Cream Attachment



Before Use

- Clean the inner and outer buckets and mixing blade in warm water with a soft cloth or sponge. Rinse and wipe dry. Place the inner and outer buckets back together.
- Freeze the bucket in an upright position for at least 16 hours or more.
- Remove the bucket from the freezer, the bucket needs to be completely frozen before making ice cream. If you shake the bucket and do not hear any liquid this means the bucket is completely frozen.

USE

- Attach the gearbox on the bottom of the ice cream attachment.
- Place the ice cream attachment with gear in place into the breadmaker and twist clockwise into the slot.
- Make sure the mixing blade is mounted on the lid and place the lid on the bowl.
- Place ingredients inside the bowl, make sure that they are chilled to get the best results. If ingredients such as chocolate chips are desired open the bowl during the last two minutes for mixing. The default time for the ice cream mode is 20 minutes.
- Follow the instructions for how to use the bread maker in the main unit instruction manual and select function 16.

Note: Due to fresh ingredients being used, the ice cream will have a softer consistency than store bought ice cream.

CARE

- Clean the bowl and mixing blade in warm water with a soft cloth or sponge.
- Rinse and wipe dry.
- Do not use scouring pads or abrasive cleaners. Use a soft damp cloth to clean the outside the bucket.

LIMITED ONE YEAR WARRANTY

This warranty covers all defects in workmanship or materials in the parts arising under normal use and care in this product for a period of 12 months from the date of purchase provided you are able to present a valid proof-of-purchase. A valid proof-of-purchase is a receipt specifying item, date purchased, and cost of item. A gift receipt showing item and date of purchase is an acceptable proof-of-purchase. Product is intended for household use only. Any commercial use voids the warranty.

This warranty covers the original retail purchaser or gift recipient. During the applicable warranty period within normal household use, we will repair or replace, at our discretion, any part which proves defective, or replace unit with a comparable model. Shipping and handling costs are not included for warranty replacements and are the responsibility of the customer.

To obtain service under the terms of this warranty, call our customer care department at 312-526-3760 (Monday- Friday 10:00AM-6:00PM CST), or send an email to customercare@alliedrich.net. Please provide the model number listed on the bottom of this page when contacting us.

THIS LIMITED WARRANTY COVERS UNITS PURCHASED AND USED WITHIN THE UNITED STATES AND DOES NOT COVER:

- Damages from improper installation.
- Damages in transit.
- Defects other than manufacturing defects.
- Damages from misuse, abuse, accident, alteration, lack of proper care and maintenance, or incorrect current or voltage.
- Damage from service by other than authorized dealer or service center.
- Shipping and handling costs.
- This warranty gives you special legal rights and you may also have other rights to which you are entitled which may vary from state to state.

Manufacturer does not assume responsibility for loss or damage for return shipment. We recommend that you keep your original packaging should you require repair service. Before returning product please contact our customer care department for return authorization. When returning product for repair please include your full name, return address, and daytime phone number. Also include a brief description of the problem you are experiencing and a copy of your sales receipt or other proof of purchase in order to validate warranty status.

MODEL PDBMIC1