

# Quick Start Guide

# SHAQ<sup>TM</sup> Grill & Press

See owner's manual for complete instructions and important safety information before using this product.

## STEP 1



Assemble the appliance and ensure that the Grill Plate and Drip Trays are in place (see reverse side for detailed instructions). Plug the Power Cord into an outlet.

## STEP 2




Close the Lid.  
Set a cooking temperature. Allow the appliance to preheat. When the appliance has preheated, the Indicator Light will turn off.

## STEP 3



Use the handle to open the Lid and place your food on the Bottom Grill Plate.

## STEP 4



When your food is done cooking, use a plastic or wooden spatula to transfer the food to a plate or cutting board.

**IMPORTANT:** Unpack all parts from the box and remove any clear or blue protective film on the components. Wash with warm, soapy water before first use (only select accessories are dishwasher safe).



\*Griddle Plate may be sold separately.

**NOTE:** The Top and Bottom Grill Plates are removable.  
The Top Heating Element is fixed and cannot be removed.