


## Inflating Your Board

Locate valve near tail of board and open protective cap. Make sure valve is in the closed position (center valve pin up). If the valve is in the open position, press down on the valve pin & turn it counter clockwise until it pops up. Take out your pump. Make sure the pump hose is connected to the "OUT" port on the pump. Insert the pump nozzle into the valve receptacle by applying firm inward pressure and clockwise twisting motion to lock in place.



## Fin Installation

Locate the fin slider insert at the bottom of the board. Slide and secure the fin into place.





## How to Tighten the Valve

After inflating and deflating 2 to 3 times, the valve may become loose. Deflate first, use the tool in the repair kit to gently tighten the valve.



## Deflation:

Open Protective cap. Depress center pin on valve to allow air to escape. To remove excess air, simply apply pressure and squeeze the paddle board until the undesired air has been released.



## Board Folding Steps

Before storing, remove loose dirt from the board and allow to dry completely to prevent mildew. The board storage bag is designed to allow you to get your board into the bag as easily as possible with minimal folds. With valve protective cap off and valve pin open follow the diagram below for best folding procedures. Remove fin prior to folding. Images shown have optional center fin box.

## Limited Lifetime Warranty

Your Activa product is backed by a limited lifetime manufacturer's warranty. Activa will repair or replace your device at any time should it fail due to a defect in material or workmanship, subject to the certain limitations.

This limited warranty does not cover any damage that results from unauthorized or improper use, service, or repair. Further, it does not cover damage caused by accident, impact, negligence, or normal wear and tear. Should you discover your Activa product is not functioning properly, please send your device to our repair center for evaluation. If your product cannot be repaired or serviced, we will reserve the right to change it for a similar or newer model.

Please note that a flat rate of \$150.00 will be charged to cover a service evaluation fee and return shipping of your device. All warranty claims must be accompanied by a copy of your proof of purchase from an authorized retailer. Please send your device, proof of purchase, and a check or money order in the amount of \$150.00 made out to Activa to:

Address:

Activa Service Center

3069 Taft Street

Hollywood, FL 33021

Contact:

warranty@activaofficial.com